



City of Santa Barbara

Storm Water BMP Guidance Manual

Training for City Staff



Brandon Steets, PE, Senior Water Resources Engineer
Deb Stewart, PE, Water Resources Engineer



City of Santa Barbara Creeks Division • June 25, 2009



Manual Chapters

- Chapter 1: Introduction
 - Manual Purpose
 - NPDES Phase II SWMP Requirements
 - Project Tiers & Design Review Process
 - How to Use the Manual
- Chapter 2: Site Assessment and BMP Selection
- Chapter 3: Site Soil and Infiltration Assessment
- Chapter 4: Site Design BMP Options



Manual Chapters

- Chapter 5: Basic BMP Options
- Chapter 6: Storm Water Runoff BMP Options
 - BMP Sizing Requirements
 - Design Specifications
 - Operations and Maintenance Requirements
- Appendices



Manual Purpose

- Reduce surface water pollution from urban storm water runoff and address existing water quality challenges
 - Urban runoff is the **#1 contributor** to surface water pollution in Santa Barbara
 - Over 15 Santa Barbara water bodies were proposed to be listed as “impaired” by the regional water board last year



Manual Purpose (cont'd)

- Provide guidance to City staff and residents for meeting the City's Storm Water Management Program (SWMP) requirements
- Requirements apply to post-construction runoff
 - Post-construction runoff: storm water runoff after construction activities have been completed



SWMP Requirements

- City is required to implement a SWMP under the Federal Clean Water Act
- City's SWMP was approved in January 2009
- City currently implementing year one of the five-year SWMP requirements



City of Santa Barbara
National Pollutant Discharge Elimination System (NPDES)
Storm Water Management Program
January 2009

Santa Barbara Storm Water Management Program Contact:
Cameron Benson, Creeks Restoration/Clean Water Manager
City of Santa Barbara
Creeks Restoration/Water Quality Improvement Division
P.O. Box 1990
Santa Barbara, CA 93102-1990
Telephone: (805) 897-2508
FAX: (805) 897-2626
Email: CBenson@SantaBarbaraCA.gov
Web: www.SantaBarbaraCA.gov



SWMP Requirements

- SWMP must include 6 sections:
 - Public Education
 - Public Participation
 - Illicit Discharge Detection and Elimination
 - Construction Site Storm Water Runoff Control
 - **Post-Construction Runoff Control BMPs**
 - Pollution Prevention/Good Housekeeping
- Post-construction runoff control requirements vary by project type



Project Tiers & How to Use the Manual

- Tier 1 – Small Projects
 - Projects with < 500 sq. ft. of new or replaced impervious area
- Tier 2 – Medium Projects
 - Residential projects with 500 to 4000 sq. ft. of new or replaced impervious area
- Tier 3 – Large Projects
 - Residential with > 4000 sq. ft. of new or replaced impervious area, commercial, mixed use, parking lots w/ ≥ 10 spaces, hillside residential, and public works projects




Project Design Review Process

- **Tier 1**
 - Voluntary implementation of any BMP types
- **Tier 2**
 - Include in simple site plan:
 - One or More Basic BMPs (Chapter 5) – *Required*
 - Site Design and Storm Water Runoff BMPs (Chapters 4 and 6) – *Voluntary*



Tier 2 – Simple Site Plan




Project Design Review Process

- **Tier 3**
 - SWMP Sizing Requirements Apply
 - DART SWMP Checklist
 - Responsible City staff identified
 - Preliminary Hydrology/Water Quality Plan Required



Tier 3 SWMP Application Example



Chapter 4: Site Design BMP Options

- Conserve and restore natural areas
- Maintain, restore, and utilize natural flow paths
- Site BMPs on infiltrative soils
- Minimize soil disturbance and compaction
- Minimize impervious surfaces
- Disconnect impervious surfaces and utilize pervious areas




Conserve and Restore Natural Areas

- Preserve undisturbed natural areas/riparian buffers
- Preserve natural topography
- Avoid steep slopes & floodplains
- Minimize siting on erodible soils



Site BMPs on Infiltrative Soils

- Hydrologic soil group types A and B are most suitable for BMPs that are designed for partial or full infiltration




Minimize Soil Disturbance & Compaction

- Fit design to terrain
- Minimize clearing & grading to development envelope
- Save A and B soils
- Limit lot disturbance
- Use soil amendments
- Locate development in less sensitive areas
- Utilize open space



Minimize Impervious Surfaces

- Reduce road lengths and widths
- Reduce building footprint
- Reduce setbacks and frontages
- Create parking lot stormwater islands
- Reduce parking footprint
- Use alternative surfaces



Disconnect Impervious Surfaces and Utilize Pervious Areas


Drain runoff to:

- Riparian buffers
- Pervious vegetated areas
- Natural drainage ways
- Basic and storm water runoff BMPs

Instead of storm drain systems



Site Design Example



Chapter 5: Basic BMP Options

- Required for:
 - Tier 2
 - Tier 3 – where applicable
- No sizing requirements
- Easier to implement than storm water runoff BMPs (Chapter 6)
- Recommended simple site assessment and soil testing for Tier 2



Chapter 5: Basic BMP Options

Disconnect downspouts



Flow spreading

Chapter 5: Basic BMP Options

- Rain Gardens
 - Less than 300 sq. ft. in area, or
 - Captures runoff from less than 4,000 sq. ft. of impervious area
 - If greater, size as a bioretention area (Section 6.6.1)




Chapter 5: Basic BMP Options



Rain Barrels

Contained Planters



Chapter 5: Basic BMP Options



Depression Storage

Ribbon
“Hollywood”
Driveways




Permeable Pavement for
Single-Family Residences



Chapter 5: Basic BMP Options



Soil Amendments



Native Landscaping
(Local Plant List: Appendix G)



Chapter 6: Storm Water Runoff BMPs

- Required for Tier 3 projects
 - Except for exemptions (App. J)
- Site and soil assessment
 - Chapters 2 and 3
- Site design and basic BMPs
 - Chapters 4 and 5
- BMP selection procedure
 - Chapter 2 and Section 6.3
 - Prioritize 'above ground' BMPs first
- BMP sizing requirements
 - Section 6.2 and Appendix C



Chapter 6: Storm Water Runoff BMPs

- BMP design specifications
 - 13 BMPs included in the Manual
 - BMP design examples – Appendix D
 - Basin outlet sizing examples – Appendix E
 - Local plant list – Appendix G
- BMP operations & maintenance
 - Inspection & maintenance checklists – Appendix H
 - Example access & maintenance agreements – Appendix I
 - Example inspection & violation notifications – Appendix I



Storm Water Runoff BMP Selection Procedure

Identify Site & Soil Conditions and Primary Pollutants of Concern:



Identify storm water runoff BMPs with high or very high treatment effectiveness: Table 6-1



Identify which of the BMPs from Table 6-1 are suitable for the site: Table 6-2



Also consider cost and long-term maintenance considerations



Chapter 3: Site Soil and Infiltration Assessment

- Preliminary site investigation
 - Soil maps provide a very general idea of soil type
 - Identify locations where development will likely have the least impact
 - Identify locations where BMPs will likely be most suitable
- Test pit investigation
 - Identify overall soil conditions to a given required depth below the soil surface
 - Pits should be excavated to 3' below proposed bottom of non-infiltration BMPs and 11' below infiltration BMPs



Chapter 3: Site Soil and Infiltration Assessment

- Infiltration testing
 - Measures infiltration rate below BMP
 - Should occur at the proposed bottom of the BMP of each test pit
 - If fill is present within 11' of bottom of BMP, a second test should be conducted at the interface
 - Measured infiltration rates should be between 0.5 and 2.4 in/hr (add a design safety factor of 0.25-0.5)
- Infiltration testing types
 - Falling-head infiltration testing (in-situ)
 - Lab soil tests for proposed fill beneath BMP (ex-situ)



Storm Water Runoff BMP Sizing Requirements

- Three sizing requirements (Section 6.2 and Appendix C)
 - Peak runoff discharge rate requirement
 - Volume reduction requirement
 - Water quality treatment requirement
- Peak Runoff Discharge Rate Requirement
 - Only for Tier 3 projects requiring Planning Commission Review
 - Post-development peak storm water runoff discharge rate \leq pre-development rate, up to a 25-yr, 24-hr storm event
 - Pre-development is defined as the existing land use condition prior to the proposed development activity



Storm Water Runoff BMP Sizing Requirements (cont'd)

- Volume Reduction Requirements
 - Only for Tier 3 projects requiring Planning Commission review
 - Retain on-site the larger of the following two volumes:
 - Volume difference between pre- and post-development conditions for the 25-yr, 24-hr design storm.
 - Volume generated from a one-inch, 24-hr storm event.
- Water Quality Treatment Requirements
 - For all Tier 2 or Tier 3 discretionary projects
 - Volume-based BMPs must be sized for 1-inch, 24-hr design storm
 - Flow-based BMPs must be sized for a rainfall intensity = 0.25 in/hr for a minimum of 4 hours




Strategies for Meeting the Requirements

- Volume reduction and water quality treatment requirements are not additive
 - Can be met simultaneously in many cases when using BMPs that allow for infiltration
- Reduce requirements by also using:
 - Site design BMPs (Chapter 4)
 - Basic BMPs (Chapter 5)
- Utilize treatment trains
- Add a gravel storage layer to increase infiltration



Treatment Train Concept




Section 6.6.1: Bioretention


- **Description**
 - Landscaped shallow depression that captures, temporarily stores, filters, and infiltrates storm water runoff
- **Applications**
 - Commercial, mixed use, institutional, residential
 - Parking lots, cul-de-sacs, traffic circles
 - Road shoulders & medians
- **Treatment Effectiveness & Site Suitability**
 - Tables 6-1 and 6-2



Infiltration Bioretention System



Filtration Bioretention System



**Impervious or highly
pervious soils**



DebS33


Where does this pipe lead. Explain this.

Deb Stewart, 6/8/2009



Section 6.6.1: Bioretention

Figure 6-2



Section 6.6.1: Bioretention

- Sizing Methodology
 - Determine the design infiltration rate
 - Infiltration rate testing (Chapter 3)
 - Apply a safety factor
 - Sizing calculations – determine surface area
 - Simple sizing method
 - Routing method – continuous simulation model
- Plant Selection
 - Must tolerate drought and periods of inundation up to 48 hours (w/o gravel drainage layer) or 72 hours (w/ gravel drainage layer)



Section 6.6.1: Bioretention

- Operations & Maintenance
 - General Requirements
 - Pruning/plant removal
 - Watering (up to 5 years)
 - Address erosion problems
 - Mulch replacement
 - Planting soil replacement
 - Maintenance Quick Guide
 - Table 6-7
 - Routine Maintenance Reqt's
 - Table 6-8



Common Causes of BMP Failure



Inadequate soil infiltration rate

Clogging due to unstabilized site



Lack of maintenance




Section 6.6.2: Vegetated Swales

- Description
 - Open shallow channels with low-lying vegetation covering the side slopes and bottom
- Applications
 - Commercial, mixed use, institutional, residential, multi-family
 - Parking lots, cul-de-sacs, traffic circles, road shoulders & medians
 - Open space, parks, golf courses




Section 6.6.3: Vegetated Filter Strip

- Description
 - Vegetated area that filters sheet flow runoff from adjacent impervious surfaces
- Applications
 - Roads and highway shoulders
 - Small parking lots
 - Residential, commercial, or institutional landscaping



Section 6.6.4: Sand Filter

- Description
 - Contained sand bed filter with an underdrain system
 - Pretreatment is required
- Applications
 - Roads, highways, parking lots
 - Commercial and industrial
 - Roof runoff
 - Golf courses and open spaces



Section 6.7: Infiltration BMPs

- Description

- Infiltration Basins

- Shallow flat depression with vegetated bottom and sides



- Infiltration Trenches

- Long, narrow trench filled with aggregate or prefab material



- Drywells

- Excavated pit filled with aggregate or prefab material



- Applications

- Commercial, residential, institutional
 - Roads, parking lots, parks, open spaces



Section 6.9.1: Cistern/Rain Barrel

- Description
 - Large rain barrels with capacity > 100 gallons
 - Collect and temporarily store runoff from rooftops for later use as irrigation or non-potable uses
- Applications
 - Any type of land use, provided adequate end use of water



Section 6.9.2: Planter Boxes

- Description

- Boxes filled with gravel on bottom (for underdrain), planting soil media, and vegetation
- Placed adjacent to buildings to capture roof runoff





- Applications

- Commercial, residential, institutional
- Mostly commonly used in urban areas adjacent to buildings and sidewalks



Section 6.9.3: Green Roofs

- Description
 - Roofing systems that layer a soil/vegetative cover over waterproofing membrane
- Types
 - Extensive – light weight system
 - Intensive – heavier weight system that allows for larger plants
- Applications
 - Commercial, residential, institutional
 - Parking decks



Section 6.10.1:

Constructed Treatment Wetlands

- **Description**
 - Wetland with varying depths with aquatic vegetation covering a significant portion of the basin
 - Includes one or more permanent micro-pools (3 to 5 feet deep)
 - Sediment forebay settles out coarse solids
 - Basin outlet structure sizing – Appendix E
- **Applications**
 - Regional detention & treatment
 - Large footprint needed



Section 6.10.2: Wet Retention Basins

- Description

- Constructed, naturalistic ponds with a permanent or seasonal pool of water
- Require base flow to maintain permanent pool
- Can be designed to provide extended detention
- Sediment forebay settles out coarse solids
- Basin outlet structure sizing – Appendix E



- Applications

- Regional detention and treatment



Section 6.10.3:

Dry Extended Detention Basins

- Description
 - Basins whose outlets have been designed to temporarily detain storm water
 - Can promote infiltration by adding a sand filter beneath the basin
 - Sediment forebay settles out coarse solids
 - Basin outlet structure sizing – Appendix E
- Applications
 - Regional detention and treatment



Conclusions

- City SWMP is a City document NOT just a Creeks Division document
 - Department wide responsibility
- Water quality challenges have developed on an incremental basis
 - Need incremental solutions





"Never, ever, think outside the box."

Questions?